

ELEMENT™ SERIES

ELEMENT ACTIVE SYSTEM



ELEMENT ACTIVE SYSTEM VTC




Detailed installation instructions are available for authorized dealers at [**lrbaggs.com/support**](http://lrbaggs.com/support)

Register your pickup system at
[**lrbaggs.com/product-registration**](http://lrbaggs.com/product-registration)

ELEMENT

ACTIVE SYSTEM




VOLUME CONTROL

Roll this wheel towards the neck to increase the volume or towards the bridge to decrease the volume.

ELEMENT

ACTIVE SYSTEM VTC



VOLUME CONTROL

Roll this wheel towards the neck to increase the volume or towards the bridge to decrease the volume.

TONE CONTROL

Roll this wheel towards the neck to increase treble frequencies or towards the bridge to decrease treble frequencies. Center detent position is unaffected.